Aircraft radar station TsD-ZOT

From the mixer output, the pulses are sent to start the transmitter. The pulse delay corresponds to the following scanning phases of the feed:

2 μs for 0 ° phase

5 μs for 90 ° phase

3 μs for 180 ° phase

4 μs for 270 ° phase

Angle reporting is clockwise when viewed in the direction of flight.

one 2 3 4 five